

Vessel Isolation Connection Valve

Size: 3/4"

When purchasing a vessel this vessel isolation connection valve should be fitted.

This allows the vessel to be removed for maintenance without draining the fluid from the system.

