

Unvented Expansion Kit U1

When installing small unvented water heaters, it is essential that the correct accessory packs are used.

For use with 10 and 15 Ltr Unvented Units Only

The pressure reducing valve limits water pressure to 3 bar.

The strainer filters coarse impurities from the water supply.

Installation: The U1 must be installed on the cold inlet side of the heater and before the expansion vessel.

Where possible, installation should be on the mains side of the cold water tap draw off. This will result in balanced water supplies and is particularly important when mixers are to be used.

Where Pack U1 is fitted with an unvented water heater, it must be used with Pack U2.

