

Unvented Expansion Kit U5

When installing small unvented water heaters, it is essential that the correct accessory packs are used.

The Expansion Vessel, when fully charged, will absorb all expanded water produced by the unvented heater during normal operation. The Check Valve prevents backflow of hot water and eliminates any possibility of cross-contamination between cold and hot water.

2 Ltr expansion vessel supplied with a check valves to prevent cross contamination.

