

## Zip AQ2 Unvented Kit

Consisting of:

Expansion Vessel and check valve (3.5 bar)



### Unvented Accessory Selection

Will the pipework accommodate expanded water without hot water entering any supply pipe connected to a cold water draw-off? (See diagram A opposite and note minimum pipe lengths). If expansion in the cold water main is restricted, e.g. by a valve or meter, an expansion vessel and other relevant accessories **MUST** be fitted.

